

PULSE TIME = R1 X C1

CURRENT DRAIN = 3uA

DESIGNED BY DAVE JOHNSON
DISCOVERCIRCUITS.COM
ALL RIGHTS RESERVED

DRAWN BY: DAVE JOHNSON